

ASTRO WARS

- Insert coin (s).
- Select one or two player game.
- If two player game is selected, players play alternately.
- Operate the control buttons to move your ship to the right or to the left.
- Four independent groups will appear before the Master appears.
- Watch your fuel supply.
- You must destroy the Master before you can refuel.
- If you lose all your ships the game is over.